

Large Assembly Instructions

Tools Needed: Phillips head screwdiver



The two piece Booster Bath is designed to snap together one time only and is not designed to come apart once connected.



proper locations before applying holes at the bottom of each leg. firm downward pressure.



Confirm all #13 snaps are in their Push rubber bumpers into receiving



Attach legs as shown. Note: Make Push drain hose on as shown. Flip sure that the legs marked with an "A" are located in front of the Booster Bath. Legs marked "B" are design to be attached at the rear.



tub upright when complete.



Install 4 mat clips using 8 small screws as shown.



Place leash restraint in T-formation Place plastic washers over steel as shown.

MADE IN USA



eyehooks. Push eyehook through hole in side wall of tub and screw on the 3 plastic knobs firmly.



Install Shampoo Caddy in rear sidewall of tub.